

Somos® WaterShed® Black

Stereolithography

Multipurpose resin that prints 50% faster than alternatives, eliminates the need for painting.

Somos WaterShed Black, with similar properties and processing as Somos WaterShed XC 11122, has up to a 50% faster processing speed than alternative black resins, offering minimal finishing and more consistent processing over time. Compared to alternatives currently on the market, Somos WaterShed Black prints a more true black color off the machine. The material offers a smooth surface finish, as well as higher moisture and chemical resistance.



Key Benefits

- Best-in-class environmentally durability performance - measured using industry standard testing methods rather than just UV light
- Ease-of-use and fast processing with minimal finishing, more consistent processing over time
- A more true black color off the machine
- Based on proven technology of
- Somos WaterShed XC 11122
- Smooth surface finish
- Higher moisture and chemical resistance

Ideal Applications

- Durable, stiff, tough parts
- Automotive components
- Electronic housings
- Packaging
- Functional prototypes and end use parts

LIQUID PROPERTIES		OPTICAL PROPERTIES		
Appearance	Black	E _c	8.4 mJ/cm ²	[critical exposure]
Viscosity	~260 cps @ 30°C	D _P	4.15 mils	[slope of cure-depth vs. In (E) curve]
Density	~1.127 g/cm3 @ 25°C	E ₁₀	93.4 mJ/cm ²	[exposure that gives 0.254 mm (.010 inch) thickness]



MECHANICAL PROPERTIES		UV POSTCURE	UV POSTCURE	
ASTM	Property Description	Metric	Imperial	
D638M	Tensile Strength at Break	50.4 MPa	7.3 ksi	
D638M	Elongation at Break	15.	.5%	
D638M	Elongation at Yield	3	%	
D638M	Tensile Modulus	2,770 MPa	402 ksi	
D790M	Flexural Strength	68.7 MPa	10 ksi	
D2240	Flexural Modulus	2,205 MPa	320 ksi	
D256A	Izod Impact (Notched)	25 J/m	0.47 ft-lb/in	
D570-98	Water Absorption	0.3	35%	

THERMAL/ELECTRICAL PROPERTIES		UV POSTCURE		
ASTM	Property Description	Metric	Imperial	
E831-05	C.T.E. 40°C – 0°C (-40°F – 32°F)	67 µm/m°C	37 µin/in°F	
E831-05	C.T.E. 0°C – 50°C (32°F – 122°F)	93 µm/m°C	52 µin/in°F	
E831-05	C.T.E. 50°C – 100°C (122°F – 212°F)	180 µm/m°C	100 µin/in°F	
E831-05	C.T.E. 100°C – 150°C (212°F – 302°F)	187 µm/m°C	104 µin/in°F	
D150-98	Dielectric Constant 60 Hz	2	ļ.	
D150-98	Dialectric Constant 1KHz	3.	8	
D150-98	Dielectric Constant 1MHz	3.	5	
D149-97a	Dielectric Strength	15.9 kV/mm	404 V/mil	
E1545-00	Тд	43°C	109°F	
D648	HDT @ 0.46 MPa (66 psi)	50°C	122°F	
D648	HDT @ 1.81 MPa (264 psi)	49°C	120°F	

Mechanical and Thermal/Electrical Properties based on Somos WaterShed XC 11122. The Liquid and Optical Properties are specific to WaterShed Black.

Figure 1: Stress Strain Curve



Stress Strain Curve

This stress strain curve visualizes the behavior of the material as force is applied.

Somos WaterShed Black exhibits plastic behavior, with a yield point, followed by plastic deformation.

Environmental Durability

There are many accelerated tests available to determine the aging performance of materials. Since these are accelerated tests, understanding the key exposure factors in the application is critical to choosing the appropriate test. This is because materials respond differently to the conditions of irradiation, heat and moisture. It is also critical when sharing data, to explicate test conditions so that users can determine how to factor performance to their requirements. Finally, showing correlations to actual weathering is only valid if one has weathered their materials in those real conditions. Below results illustrate the case for exterior exposure.

Figure 2: Xenon Arc Irradiation (Source: Q-Lab)



stratasys

A standard test developed for the automotive industry for exterior exposure is SAE J2527. This standard utilizes a light source that replicates sunshine across the spectrum. Figure 1 compares a Xenon source to the commonly used UVA lamp source.

Irradiation Intensity	340mm	295-400mm	300-800mm
Xenon Light (J2527)	0.55 W/m ²	60 W/m ²	550 W/m ²
Fluorescent (UVA-340)	0.55 W/m ²	32 W/m ²	-

Xenon arc lamps represent very well solar radiation spectral distribution. Total Irradiance is much higher with a Xenon source:

The SAE J 2527 Test is conducted using conditions and cycle as shown in Figure 3:

SAE J2527 is one accepted standard for exterior weathering testing

Figure 3: SAE J2527 Test Cycle





Weathering Performance

Figure 4 shows the weathering performance of Somos WaterShed Black and compares it to an alternative photopolymer commercialized for weatherable applications. The alternative shows good property retention when exposed to UV light with the commonly used UVA lamp. When exposing the resin to a Xenon Arc lamp - a test method that mimics more closely actual sun light - the performance goes down faster and stabilizes on a much lower level. To avoid major discrepancy between anticipated material behavior and actual material behavior of parts in the field, matching accelerated test with real live conditions is critical.

Figure 4: Xenon Arc Irradiation (Source: Q-Lab)



Figure 5: Chemical resistance

Substance	Resistance
Water	Excellent
Saline (0.9%)	Excellent
Gasoline	Excellent
Diesel Fuel	Excellent
Engine Oil	Excellent
Windshield Wash	Good
Ethylene Glycol	Excellent
Brake Fluid	Excellent
Transmission Fluid	Excellent
Acetone	Good
Isopropanol	Excellent
Ethanol	Good
Methanol	Fair
Bleach	Good

Chemical Compatibility

Somos WaterShed Black shows good resistance to many common chemicals.¹

Chemical compatibility tests performed on the transparent version, Somos WaterShed XC11122.



Retention of Mechanical Properties After Exposure

Figure 6: Tensile Modulus Retention of Somos WaterShed Black after 7-Day Immersion



This graph shows the retention of tensile modulus after 7-day immersion in the listed substance. Somos WaterShed Black maintains properties well when subjected to these materials. If you require data from other chemicals, please reach out to our Technical Service Team.

Figure 7: Elongation at Break Retention of Somos WaterShed Black after 7-Day Immersion



This graph shows the retention of tensile elongation after 7-day immersion in the listed substance. Somos WaterShed Black maintains elongation and ductility well when subjected to these materials. If you require data from other chemicals, please reach out to our Technical Service Team.

USA - Headquarters

7665 Commerce Way Eden Prairie, MN 55344, USA +1 952 937 3000

ISRAEL - Headquarters

1 Holtzman St., Science Park PO Box 2496 Rehovot 76124, Israel +972 74 745 4000

stratasys.com

ISO 9001:2015 Certified

EMEA

Airport Boulevard B 120 77836 Rheinmünster, Germany +49 7229 7772 0

ASIA PACIFIC

7th Floor, C-BONS International Center 108 Wai Yip Street Kwun Tong Kowloon Hong Kong, China + 852 3944 8888



GET IN TOUCH. www.stratasys.com/contact-us/locations

© 2023 Stratasys Ltd. All rights reserved. Stratasys, Stratasys signet, Somos and WaterShed are trademarks or registered trademarks of Stratasys Ltd. and/or its subsidiaries or affiliates and may be registered in certain jurisdictions. All other trademarks belong to their respective owners. Product specifications subject to change without notice. MDS_SL_Somos_WaterShed_Black_A4_0723a

