

Tango POLYJET SIMULATED RUBBER MATERIAL

Flexible Tango™ material exhibits rubber-like qualities to simulate soft-touch coatings, non-slip surfaces, overmolding grips, shoe soles and other applications requiring flexible characteristics. Tango material is available in black, gray and translucent colors, and in a range of Shore A hardness values comparable to rubber bands, tire treads and shoe heels.



TO LEARN MORE ABOUT TANGO VISIT STRATASYS.COM





At the core: PolyJet™ Technology

PolyJet technology creates precise prototypes that set the standard for finished-product realism. Their fine resolution makes complex shapes. intricate details and smooth surfaces possible. PolyJet 3D Printing works by jetting layers of liquid photopolymer onto a build tray and instantly curing them with UV light. The fine layers build up to create a precise 3D model or prototype. Models are ready to handle right out of the 3D printer, with no post curing needed.

Keep valuable resources in-house

You'll be amazed when you see how easy it is to produce realistic models in-house. PolyJet 3D Printers offer not only unparalleled speed, they make it easy for you to print with the widest range of material properties.

No special facilities needed

You can install PolyJet 3D Printers just about anywhere. No special venting is required because PolyJet 3D Printers don't produce noxious fumes, chemicals or waste.

Good ideas sell easier

PolyJet 3D Printers improve communication and collaboration because they produce amazingly accurate representations of your ideas that you can share with your team and your clients for a faster, more confident buy-in.

TangoBlackPlus FLX980 and TangoPlus FLX930				
	ASTM	METRIC	ENGLISH	
Tensile Strength	D-412	0.8-1.5 MPa	115-220 psi	
Elongation at Break	D-412	170-220%	170-220%	
Compressive Set	D-395	4-5%	4-5%	
Shore Hardness (A)	D-2240	26-28 Scale A	26-28 Scale A	
Tensile Tear Resistance	D-624	2-4 Kg/cm	18-22 lb/in	
Polymerized Density	D-792	1.12-1.13 g/cm³		

TangoBlack FLX973					
	ASTM	METRIC	ENGLISH		
Tensile Strength	D-412	1.8-2.4 MPa	115-220 psi		
Elongation at Break	D-412	45-55%	45-55%		
Compressive Set	D-395	0.5-1.5%	0.5-1.5%		
Shore Hardness (A)	D-2240	60-62 Scale A	60-62 Scale A		
Tensile Tear Resistance	D-624	3-5 Kg/cm	18-24 lb/in		
Polymerized Density	D-792	1.14-1.15 g/cm ³			

TangoGray FLX950					
	ASTM	METRIC	ENGLISH		
Tensile Strength	D-412	3-5 MPa	435-725 psi		
Elongation at Break	D-412	45-55%	45-55%		
Compressive Set	D-395	0.5-1.5%	0.5-1.5%		
Shore Hardness (A)	D-2240	73-77 Scale A	73-77 Scale A		
Tensile Tear Resistance	D-624	8-12 Kg/cm	50-60 lb/in		
Polymerized Density	D-792	1.16-1.17 g/cm ³			

SYSTEM AVAILABILITY	LAYER THICKNESS CAPABILITY	SUPPORT STRUCTURE	AVAILABLE COLORS
Objet30 Prime™	28 microns	SUP705 (WaterJet removable) SUP706 (Soluble)	Black, Gray
Objet260/500 Connex1™	16 microns	SUP705 (WaterJet removable) SUP706 (Soluble)	Black, Gray, Translucent
Objet260/350/500 Connex3™	16 microns		Black, Gray, Translucent
Stratasys J735™, Stratasys J750™	14 microns		Black, Gray, Translucent
Objet1000 Plus™	16 microns	SUP705 (WaterJet removable)	Black, Translucent



HEADQUARTERS

7665 Commerce Way. Eden Prairie, MN 55344

- +1 800 801 6491 (US Toll Free)
- +1 952 937-3000 (Intl)
- +1 952 937-0070 (Fax)

1 Holtzman St., Science Park, PO Box 2496 Rehovot 76124. Israel

+972 74 745 4000

+972 74 745 5000 (Fax)