

A ScanControl+™ Ready Material:
Optimized performance when used
with the Neo®800+ printer.

Somos® Resolute Grey™

Stereolithography

High-Impact, Engineering-Ready Durability

When your engineering team needs to rapidly produce functional prototypes with high-impact resistance and long-term durability, **Somos® Resolute Grey™** delivers. This premium, engineering-ready SLA material is ideal for functional testing applications across industrial, consumer and automotive industries. Developed for demanding mechanical testing, it provides the robust snap-fit durability and dimensional stability required to ensure reliable, long-term performance.

Somos® Resolute Grey™ produces parts that mimic injection molding and features a smooth surface finish in a neutral color straight off the machine. Engineered for accelerated print speeds, **Somos® Resolute Grey™** delivers exceptional side-wall quality and a primer-free color that reduces post-processing, saving development time and labor costs while improving overall production cycles.

Key Benefit

- High-Impact Resistance and Long-Term Durability
- Superior Surface Finish
- High Accuracy and Dimensional Stability

Ideal Applications

- Tough, Durable Functional Prototypes
- Snap-Fit Designs
- Jigs and Fixtures



LIQUID PROPERTIES		OPTICAL PROPERTIES		
Appearance	Grey	EC	9.3 mJ/cm2	[critical exposure]
Viscosity	325 ± 50 @ 30°C	DP	4.9 mil (0.124 mm)	[slope of cue-depth vs ln (E) curve]
Density	-1.10 g/cm @ 25°C	E10	72 mJ/cm2	[exposure that gives 0.254 mm (.010 inch) thickness]
MECHANICAL PROPERTIES		UV POSTCURE		
ASTM Method	Property Description	Metric	Imperial	
D638M D638M D638M D638M D638M D790M D738 D256A D570-98	Tensile Strength at Break	30 ± 5 MPa	4.4 ± 0.7 ksi	
	Yield Stress	43 ± 5 MPa	6.2 ± 0.7 ksi	
	Elongation at Break	20 ± 5%		
	Elongation at Yield	3.4 ± 0.1%		
	Tensile Modulus	2400 ± 300 MPa	350 ± 43 ksi	
	Flexural Strength	TBD	TBD	
	Flexural Modulus	TBD	TBD	
	Izod Impact (Notched)	35 ± 5 J/m	0.65 ± 0.1 ft-lb/in	
	Water Absorption	0.4%		
	MECHANICAL PROPERTIES		UV POSTCURE	
ASTM Method	Property Description	Metric	Imperial	
E831-05 E831-05 E831-05 E831-05 D150-98 D150-98 D150-98 D149-97a D5023 D648 D648	C.T.E. -40 - 0°C (-40 - 32°F)	TBD	TBD	
	C.T.E. 0 - 50°C (32 - 122°F)	TBD	TBD	
	C.T.E. 50 - 100°C (122 - 212°F)	TBD	TBD	
	C.T.E. 100 - 150°C (212 - 302°F)	TBD	TBD	
	Dielectric Constant 60 Hz	TBD		
	Dielectric Constant 1 KHz	TBD		
	Dielectric Constant 1 MHz	TBD		
	Dielectric Strength	TBD	TBD	
	Tg	42 ± 1 °C	108 ± 2 °F	
	HDT @ 0.46 MPa (66 psi)	51 ± 2 °C	124 ± 2 °F	
	HDT @ 1.81 MPa (264 psi)	TBD	TBD	

stratasys.com
ISO 9001:2015
Certified

Stratasys Headquarters
5995 Opus Parkway,
Minnetonka, MN 55343
+1 800 801 6491 (US Toll Free)
+1 952 937-3000 (Intl)
+1 952 937-0070 (Fax)

1 Holtzman St.
Science Park
Rehovot, 7670401
Israel
+972 74 745 4000
+972 74 745 5000 (Fax)

PRELIMINARY
DATA SHEET
SLA

© 2026 Stratasys Ltd. All rights reserved. Stratasys, Stratasys signet, Somos and Resolute Grey are trademarks or registered trademarks of Stratasys Ltd. and/or its subsidiaries or affiliates and may be registered in certain jurisdictions. All other trademarks belong to their respective owners. Product specifications subject to change without notice. MDS_SL_Somos_Resolute_Grey_0826